

zenith



Thanks for
choosing Zenith!



hookup directory

page **3**



about your trakball remote

page **16**



your on-screen menus

page **20**



special features you'll want to know about

page **51**



index

page **54**

RECORD YOUR MODEL NUMBER

The model and serial number of your new TV are located on the back of the TV cabinet. For your future convenience, we suggest that you record these numbers here:

MODEL NO. _____

SERIAL NO. _____



WARNING

RISK OF ELECTRIC SHOCK
DO NOT OPEN



WARNING:

TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

To prevent fire or shock hazards, do not expose this product to rain or moisture.

POWER CORD POLARIZATION:

CAUTION: To Prevent Electric Shock, match wide blade of plug to wide slot, fully insert.

ATTENTION: Pour éviter les chocs électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

NOTE TO CABLE/TV INSTALLER:

This reminder is provided to call the cable TV system installer's attention to Article 820-40 of the National Electric Code (U.S.A.). The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.

REGULATORY INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Do not attempt to modify this product in any way without written authorization from Zenith Electronics Corporation. Unauthorized modification could void the user's authority to operate this product.

Hookup Directory

This page will help you hook up your Entertainment Machine properly.

IMPORTANT!! Use this page to decide where you need to begin your setup. First, find the line below that best describes what you want to do, then go to that page number. For a complete index go to page 54.

GENERAL HOOKUP INFORMATION

About your Jacks

For general information about the jacks on your Entertainment Machine, go to pages 4 and 5

INPUT HOOKUP OPTIONS

Antenna/Cable

If you are using an antenna or have direct cable service, go to page 6

Cable Box

If you are using a cable box, go to page 7

VCR

If you are using a VCR, go to page 8

DVD Player

If you are using a DVD Player, go to page 9

AUDIO EQUIPMENT OPTIONS

Speaker Placement

For general speaker placement advice, go to page 10

Audio Speakers

To hook up your surround sound speakers, mini tower speaker or sub-woofer, go to page 11

External Stereo


To hook up your entertainment machine to an external stereo, go to page 12



For a complete Index, see page 54-55.

Your jack-pack and its various uses.

Audio Video Jacks



Mini glossary

JACK	A connection on the back of a TV, VCR, or any other A/V device. This includes the RF jacks and the Audio/Video jacks that are color-coded.
SIGNAL	Picture and sound traveling through cable, or in the air, to your television screen.

Front A/V Jacks

Hooking up temporary equipment to your Entertainment Machine.

There are four jacks on the front of your Entertainment Machine that make connecting Audio/Video devices like video games and camcorders very simple.

The jacks are located behind a small door below the buttons on the front panel.

The jacks are like those found in the jack pack on the back of your Entertainment Machine. Which means that any equipment that connects to those types of jacks in the rear jack pack, can also be connected in front.


To use the front jacks as the signal source, use the Source menu as described on page 22. They will be named "Frnt Video" and "Frnt S-Video" in the Source menu, but if you are using something else, and don't want to get confused, change the name under the Source ID (see page 31).



When you choose Front Video or Front S-Video, the audio is automatically changed as well.



If you're connecting a video game unit, make sure to change the picture settings with the Video Preset option in the Video menu (see page 36).



Right/Left Audio
Used for stereo sound from various types of equipment.

Video
Connects the video signals from any piece of equipment.

S-VIDEO
A feature available with some very high-end equipment that provides even better picture quality.

NOTE: The picture for the IQA36A46W will be different than the one shown. However, the front jacks will be the same.

Model IQA32M46W does not have front jacks.

Mini glossary

A/V CABLES Audio/Video cables. Three cable connectors—Right audio (red), Left audio (white), and Video (yellow). A/V cables are used for stereo playback of videocassettes and for higher quality picture and sound from other A/V devices.

A/V DEVICE Any device that produces video or sound (VCR, DVD, cable box, or television).

Connecting antenna/cable to your Entertainment Machine.

Antenna/Direct Cable TV or Cable Box


Hooking up to Antenna/Direct Cable

1 Locate the Antenna/Cable 1 jack on the back of your Entertainment Machine.

2 Connect the cable that runs from the wall directly to this jack.



If you receive antenna through a wire that is several years old and connects with two small prongs, you will need to purchase a 300 Ohm adapter. It should be available from your local electronics dealer.



Cable Box

Some cable services require the use of a cable box to decode premium channels and pay-per-view. Using the Loop Out to Decoder option, and programming your remote, you can connect your cable box so that you only need your MBR Trakball remote to control all the channels. By connecting cable directly to your Entertainment Machine, then running it out to the cable box and back, you make the cable box another source to choose from in the Source menu (see page 22).

1

Locate the Antenna/Cable 2 jack on the back of your TV. Connect the cable that runs from the wall directly to the jack. Now find the the Loop Out jack.

2

Connect the cable from this jack to the Input jack on the back of your cable box.

3


Locate the Output jack on the back of your cable box. Connect this to the Antenna/Cable 1 jack on the back of your TV.

4

To view the premium stations, set the channel number on your cable box to HBO, CINEMAX, SHOWTIME, etc. Then go to the Source menu and select the Antenna/Cable 1 source. See your Quick Setup Sheet, included with this operating guide for more information. See page 22 for information regarding Source Menus.

To view the non premium channels go to the Source Menu and select Antenna/Cable 2. Then run Channel Search to check for all available channels and store them in its memory.

This can be combined with any other equipment you may want to hook up. Hook cable directly into the TV, then to the cable box. From there, the cable box goes to the next device, down the line, until the last piece, which connects back to the TV in the Antenna/Cable 1 jack.



VCR

Connecting a VCR to your Entertainment Machine.


1

Locate the RF or VHF/UHF/CATV In jack on the back of your VCR. Connect the Antenna or cable wire coming from your wall directly to this jack.

2

Find the composite video or S-Video and audio jacks on the back of your VCR, and connect them following the instructions provided with your equipment.

You may connect either the composite video or the S-Video cables to your Entertainment Machine. Do not connect both the composite and the S-Video.



To hear stereo sound from your VCR, you will need to connect A/V cables.



If you want to receive your signals on Channel 3 or 4 from Antenna/Cable 1, locate the Out to TV jack. Connect a cable from the Out to TV jack to the Antenna/Cable 1 jack on the back of your Entertainment Machine.


Optional (to receive signal on channel 3 or 4). Cable not included.

DVD Player

1

Find the audio and composite or S-Video jacks on the back of your DVD Player and connect them following the instructions provided with your equipment.


You may connect either the composite video or the S-Video cables to your Entertainment Machine. Do not connect both the composite and the S-Video.



Connecting a DVD player or S-VHS player to your Entertainment Machine.

2

Some high-end DVD players use a picture reproduction system called "component video." If your DVD player has component output, use the connectors marked "DVD" on the jack panel. Please refer to your DVD manual for proper installation.



For several pieces of equipment, edit the names under Source ID so you don't forget which is which. See page 31.

Mini glossary


COMPONENT VIDEO Some video equipment uses three separate lines (Y, R-Y, B-Y) to more precisely reproduce images. Your manual will explain how this relates to your equipment.

General help on designing your home theater set-up.

Room Set-ups for Home Theater

This is just a general room design. Any number of set-ups are possible, and some changes may be needed to maximize your sound.

A left and right speaker on either side of the Entertainment Machine will create a phantom "center channel," making the dialog sound as though it's coming directly from the Entertainment Machine. The rear surround sound speakers provide the majority of other sounds, like those from special effects in movies. Your sub-woofer generates ultra-low frequency sound, for rumbling low-end audio.



Sound is affected by speaker placement, so make sure nothing is in front of the speakers, and that they are aimed in appropriate directions.



You have the option of turning on or off the internal speakers.



If your surround sound system is on, but there's no sound from the speakers, the program you're watching might not be broadcast in surround sound.

NOTE: The picture for the IQA36A46W will be different than the one shown. However, the setup will be the same.

Audio Hookups

Get the best sound possible from your Entertainment Machine.

Before you begin plugging in your speakers, it's a good idea to put them in their approximate places first. That way you know how much wire you have or will need.

1

Locate the Surround Speakers jacks on the back of your Entertainment Machine. Connect the wires to the right or left channel, depending on where the speaker is located in your room. The copper wire corresponds to the Negative jack, and the silver to the Positive.

2


Locate the jacks marked Variable Out. These are for the sub-woofer. Connect the sub-woofer's cables, according to their color (red is the right channel, white the left) to these jacks.



If you happen to have Mini-tower speakers, these will be connected to the back of your sub-woofer, with the jack labeled Satellite Speaker Output.



If you are using an external amplifier, see page 12.



External Stereo

Combine your new Entertainment Machine with your home stereo system.

- 1


Locate the Variable Out jacks on the back of your Entertainment Machine and the Input jacks on the back of your stereo's amplifier.
- 2

Connect the two jacks, making sure that the right and left channels are placed correctly.
- 3

Set up your speakers through your stereo, according to those directions.

 You can adjust the volume level on your external stereo system even if your remote is in TV mode. See Amplifier Volume Override on page 47.

 You have the option of turning on or off the internal speakers.



Mini glossary


AMPLIFIER An external machine that amplifies sound from a television, CD player, VCR, DVD or other A/V device.

Quick Start

Have your Entertainment Machine automatically find and save all the channels available to you.


1

Use pages 6-12 to hook up your Entertainment Machine. Plug in your Entertainment Machine and press the Power button on the front panel. The Quick Start screen will instantly appear, with three steps you should follow if you have not yet done so.



2

Remove the back of the remote and put in three AAA batteries. Make sure batteries are properly installed (check the +/- signs).



3

Click ENTER on your remote to continue the setup process.

4

Your choice will be to pick 1 or 2 (Antenna or Cable), depending on the type of input signal you have.

5

You will then be prompted to press 3 on your number pad. Your Entertainment Machine will now search for all available channels, and store them in its memory.




The Quick Start menu appears the first time you turn your Entertainment Machine on, allowing you to get this out of the way before going on to other options.



The Quick Start option only works when the current source for the Main picture is Antenna/Cable 1. Once you have programmed the channels for Antenna/Cable 1 this option will not appear in the menu for another source.

4



5

3

Channel Search

Find all your available channels from any source.

This function allows you to set up the channel selection on Antenna/Cable 2. Other sources, such as VIDEO 1 and 2 won't have channels available to scan, and when they're selected as the source, the option won't even appear in the Setup menu.

1

Click on the Source Menu icon in the Menu Display.

2

Click on Ant/Cable 2 to search for available channels. This will correspond either to the name on the jack pack, or any name you may have assigned it with the Source ID option (see page 31).

3

Click on the words Inteq Source and your Setup Menu will appear.

4



Select Ch. Search in the menu by clicking on it once. Click it again to enter the Channel Search screen. You will be prompted to determine if the signal is coming from an antenna or cable. Select one or the other by pressing the correct number on the Number Keypad.

5

Press 3 on your number keypad to start the channel search for the source you've picked. You will automatically be returned to regular viewing.



When the screen tells you how many channels it found, click the Trakball twice to return quickly to regular viewing.



Projo Setup: Convergence

1

Click on your Setup Menu icon in the Menu Display at the top of the screen.

2

Select Projo Setup on your screen by clicking on it once.

3

Click again to enter the Convergence screen. You will see two intersecting lines. If the lines are perfectly white, your colors are fine. If you can see either blue or red lines, then one or both of those two colors needs to be adjusted.

4

Click on the text across the top of the screen to select which color to adjust: Red or Blue.

5

Using the Up/Down and Right/Left arrows on the remote, adjust the colors so the lines match on the screen and are completely white.

NOTE: Due to the small adjustments, it may be easier to use the arrow buttons on your remote, rather than the Trakball.



6

Click EXIT to return to the Setup Menu. Click on another option or on the regular screen to return to normal viewing.



If the lines never match up, no matter what you try, give Zenith's Projection TV helpline a call at 1-800-365-1690.

NOTE: This feature does not apply to the model IQA36A46W.



Adjust the color alignment to make your picture the sharpest it can be.

Mini glossary

CONVERGENCE This option lets you align the various colors in your picture so they look correct.

Button Functions on Your Remote

All the buttons on your remote, and what they do.

INDICATOR LIGHTS
Illuminate to show which mode your remote is in.

MODE LEFT/RIGHT
Adjust which mode your remote is working in.

MUTE

Press once for Soft Mute, again for Full Mute, and a third time to return to normal volume.

SURF

Use the regular channel selection or your customized channel Surf lists.

VOLUME LEFT/RIGHT

Increases/decreases the sound level.

SOURCE

Push to switch between available sources connected to your Entertainment Machine.

MENU

Displays on-screen menus.

RECORD, PAUSE

Control the functions on your VCR.

ARROW KEYS

Allows you to move through on-screen menu choices.

REW, FFWD, PLAY, STOP

Control the functions on your VCR.

POWER

Turn your Entertainment Machine or any other programmed equipment on or off, depending on mode.

TRAKBALL

Click and move the on-screen pointer.

FLSHBK

Return immediately to the last channel viewed.

CHANNEL UP/DOWN

Scroll through your available channels.

NUMBER KEYPAD

For direct channel selection and programming functions.

ENTER

Push to accept menu choices or after channel numbers for faster transfer.

PIP SNAPSHOT

Press to capture and freeze main picture within large PIP frame. Press a second time and receive PIP from another channel or source. Press a third time to remove PIP.

QUIT

Leaves programming menus and clears screen of displays, and provides audio swap.

Remote Control Part Number
MBR TRAKBALL: TRK 4000

Mini glossary

MODE	The mode determines the type of device (TV, VCR, Cable, AUX) that the remote is controlling.
SURF	Access a customized group of channels by pushing the surf button on the remote.

Using Your Trakball Remote

Make sure your Entertainment Machine is on. Just click the Trakball by pressing gently with your thumb, and a hand-shaped pointer will appear.

You can now move the pointer anywhere on the screen by rolling the Trakball with your thumb. As you move it from side to side, top to bottom, different menus will appear on-screen.

You can use and adjust any of these options by rolling the pointer so the index finger on the screen is touching the icon for the menu or option you want. Click the Trakball again, and the option or menu is selected.

When you're finished and want to return to normal viewing, either wait a few seconds and the pointer will disappear, or move the pointer so that it isn't touching any icons or menus, and click again.



When your pointer touches certain on-screen icons, a small text window appears to the right of the pointer, telling what the icon represents.




The point-and-click interface does everything buttons do, just like your computer. Click words on-screen instead of pressing the button. Or click on items instead of scrolling with the arrow keys.



Trakball shortcut: To quickly exit any menu screen, click on the main screen — outside the borders of the menu display.

Menu Display, which lets you access the Source menu (see page 22), the Setup menu (see pages 23-27), the Features menu (see pages 28-34), the Audio menu (see page 35), the Video menu (see page 36), and the Picture-in-picture menu (see page 39).



Learn the easiest way to get at every option on your Entertainment Machine!

Mini glossary

POINTER The image of the hand that appears on-screen and points to the option you want to work with.

ICON A small picture on your screen that represents a function or menu item.

Using Your Trakball Remote, cont'd

Learn the easiest way to get at every option on your Entertainment Machine!

- 1




When adjusting options that are on a sliding scale, such as volume, you don't have to increase or decrease them one step at a time. Just click anywhere on the spectrum, and the setting will jump to that point. From there you can fine tune the levels by clicking on the small left- and right-pointing arrows (decrease and increase, respectively), moving the levels in small steps.
- 2

Just about everywhere you see text or an icon on your screen, you can probably click there to make something happen. For example, once you have one of the items from the Menu Display on your screen, such as the Setup Menu, you can just click on the icon in the upper left of that menu to cycle through the other menus.
- 3

You can adjust the speed your Trakball moves across the screen by clicking on the small Trakball icon at the top of the PIP/Features Menu. The higher the speed you set, the more sensitive the Trakball will be to your movements.
- 4

Click on this icon to view the Captions Menu. See page 25.
- 5

To view the Sleep Timer menu, click on this icon. See page 28.




These 9 buttons adjust your Picture-in-Picture feature. See pages 37-39.

Basic TV Operation

Introducing you to the basics of your Entertainment Machine.

Source

To watch TV on antenna, cable, a VCR, DVD or any other piece of equipment, you have to make sure you've set your Entertainment Machine to the correct source. Check page 22 to see how to use the Source menu. The current source is displayed on the top line of the Channel/Time display. It will show a channel number if the source is Ant/Cable 1 or 2, and read the name of the source (such as VCR) for anything else.




Channel Changing

Click the Ch. Up/Ch. Down text to move through the channels, or use the CHANNEL UP/DOWN arrows on your remote to move through your channel list.

Skip to a specific channel by clicking on the ALL CH text and then double-clicking on a number, or by entering the number of the channel on the NUMBER KEYPAD on your remote.

To instantly return to the last channel you were watching, click FLSHBK, or press the FLSHBK button on your remote.




 This is while the source is set to Ant/Cable 1 or 2. For any other source, such as a VCR or DVD player, the Main Picture channel changing will be controlled by that equipment.

Audio

Click on any part of the Volume bar to jump to that sound level, or click on the small arrows to move in small increments. You can also use the VOLUME RIGHT/LEFT buttons on your remote to adjust the volume level.

Clicking once on the Speaker Icon in the Volume display will put your Entertainment Machine into SOFT MUTE. Clicking again will MUTE it completely, and once more will bring the sound back. Or, using the buttons on your remote, press MUTE once to reduce the sound level to the SOFT MUTE level. Press once more to completely MUTE the sound. Press again to return to full sound level.



Mini glossary

SOURCE The term for the equipment that provides audio and video information to your Entertainment Machine. VCR, DVD players, or Cable Boxes are examples of sources.

On-Screen Menus

Descriptions of all the menus on your Entertainment Machine.

Using the Menu button on your remote or by using the Trakball, you can access all the menus below.

Menu Name		Go to page
SOURCE MENU	Choose from the available sources for both the main picture and PIP.	22
SETUP MENU	Adjust the basic characteristics of your Entertainment Machine.	13-15, 23-27
Quick Start	Automatically finds and stores active channels to flip through using Channel Up/Down.	13
Channel Search	Finds and stores active channels.	14
Add/Del/Surf	Manually pick and choose which active channels will appear when flipping through using Channel Up/Down.	23
Clock Set	Set the time yourself, or program your clock to automatically detect the time, and to adjust to Daylight Savings when you program in your time zone.	24
Captions	Turn closed captioning on, off, or set it to come on automatically when the Entertainment Machine is muted.	25
Captions/Text	Choose the captioning or text method for your Entertainment Machine.	25
Language	Pick the language you want your on-screen menus to appear in.	26
Background	Turns the background for on-screen menus transparent or opaque.	27
Projo Setup	Allows you to adjust the color convergence of your Entertainment Machine.	15
FEATURES MENU	Go beyond basics and customize your Entertainment Machine's functions.	28-34
Timer Setup	Program a time for your Entertainment Machine to turn itself on or off, or to turn itself off after a certain amount of time.	28-29
Channel Labels	Label your channels with their network names (ABC, CBS, HBO, etc.).	30
Source ID	Customize the names of your sources by either selecting a label or making your own.	31
Surf ID	Design a custom channel surf selection for up to four people, and put their names on them.	32

On-Screen Menus Overview, cont'd

Descriptions of all the menus on your Entertainment Machine.

Menu Name (cont'd)		Go to page
Parental Control	Allows parents to block any channel for up to 99 hours, with the use of a password.	33
Auto Demo	Your Entertainment Machine will show you what it's capable of by running through many of its options and menus automatically.	34
AUDIO MENU	Customize the sound to suit your room and your taste. Your options are: Bass, Treble, Balance, Audio Mode, SoundRite, Front Surround, Rear Surround, BBE Audio, Speakers.	35
VIDEO MENU	Adjust your picture for any viewing situation. Your options are: Contrast, Brightness, Color, Tint, Sharpness, Color Temp, Video Filter, Skin Tone, Video Preset.	36
PIP MENU	Control the size and appearance of the PIP inset. Your options are: Contrast, Tint, Size.	38-39
	Using the Trakball, you have even more options. Click once and move the pointer around the screen to access these menus (for more information, see pages 17 and 19).	17-19
Menu Display	Access any of the on-screen menus by clicking on an icon from this list.	17
Channel/Time Display	Shows the current time, channel, video and audio source, and the Surf status.	19
Volume Display	Shows the current sound level.	19
PIP/Features Menu	Controls aspects of PIP inset and access to Trakball speed, Sleep timer and closed captioning.	18, 38

Choose the sources for your main picture and PIP.

Source Menu

This menu is where you switch input source devices so you can watch your antenna, cable TV, VCR, DVD, or anything else that you have hooked up to your Entertainment Machine. Regular antenna or cable will come through either Antenna/Cable 1 or Antenna/Cable 2, depending on how you set up your system. All other devices will correspond to the names of the jacks that they're connected to.

- 1

Click on your Source Menu icon in the Menu display.
- 2

Click on the word Main or PIP to set the signal source for that item. "Main" is for your regular picture signal, and "PIP" is for the Picture-In-Picture feature.
- 3

Click on the source where your signal is coming from. This listing will correspond to the jack names on the front and back of your Entertainment Machine, unless you changed the names under the Source ID option. To change the name of these labels see page 31.


NOTE: You cannot have the Main Source from Ant/Cable 1 and the PIP source in Ant/Cable 2 or vice versa. PIP must be the same Ant/Cable source as the main or one of the video sources.

- 4

Click on the regular screen to return to normal viewing.



Repeat these steps to set the signal source for your PIP feature.



Mini glossary

SOURCE The term for the equipment that provides audio and video information to your Entertainment Machine. VCR, DVD players, or Cable Boxes are examples of sources.

Add/Del/Surf

Create your own channel selection for cooler surfing.

- 1** Click on the Setup Menu in your Menu Display.
- 2** Click on Add/Del/Surf in the menu. Click on it again and your screen will be replaced by a large blue one with a full channel listing.
- 3** Click on the channel number you wish to modify (add/delete to your channel list). Click on channel number again to add or delete from your listing.
- 4** Click on the No Surfing text to change to a Surf channel listing (Surf 1, Surf 2, etc.).
- 5** Click on the channel number you wish to modify (add/surf to your channel list). Click on the channel number again to add it to your Surf listing. Note: Dark grey channels (deleted channels) cannot be changed.
- 6** Cycle through your other Surf modes (Surf 2, Surf 3, etc.) and repeat steps 4 and 5 to set up additional Surf channel listings.
- 7** Click on EXIT to return to the Setup Menu. Click on another option or click on the regular screen to return to normal viewing.



Instead of "Surf 1" or "Surf 2," customize the name of your program listings. See Surf ID on page 32.

The diagram illustrates the process of adding, deleting, or surfing channels. It shows the menu structure starting from the Setup Menu, then to the Add/Del/Surf option, and finally to the channel listing screen. The channel listing screen displays a grid of channel numbers (1-65) and a 'More Channels' button. It also shows the 'No Surfing' and 'EXIT' options. The diagram includes numbered callouts (1-7) corresponding to the steps in the list. A note at the bottom explains that deleted channels appear in gray and added ones in white.

Deleted channels will appear in a gray color, while Added ones will be in white.

Surfed channels will have a pink surfer icon next to them.

Mini glossary

- ADD** This function lets you add new channels to the list that you'll scroll through when using your remote.
- DELETE** This function lets you remove channels that you don't watch from the list you'll scroll through.
- SURF** This function creates a customized list of your favorite channels. You can access this group of channels by pushing the surf button on the remote or by clicking on the Surfing display (see page 17).

Clock Set

Set the clock or have it done for you, automatically. REALLY impress your friends.




- 1** Click on your Setup Menu icon in the Menu Display.
- 2** Click on Clock Set in the menu. Click it again to reach the Clock menu.
- 3** Click on Clock Mode in the menu. Click again and a display will appear at the bottom of your screen.
- 4** Choose either Auto or Manual for clock mode. Manual will let you set the time yourself while Auto will set it for you while your Entertainment Machine is off.
- 5** **Manual:** Choose Manual, then return to the Clock menu by clicking on Exit. Click on Time Set twice, and you will reach a display where you can set the time by clicking on the HH:MM AM/PM display to cycle through the times.
or
- 6** **Auto:** Choose Auto, then return to the Clock menu. Click twice on PBS Channel, then use the NUMBER Keypad to enter the PBS Channel. Your current channel will change to that station.
- 7** Turn off your Entertainment Machine for ten seconds to activate the correct time.



Embedded in the PBS broadcast signal is the information for the correct time and date. Your Entertainment Machine will read that information and automatically display the right time.



If you follow these steps and your time is still one hour off, check your Time Zone and Daylight Savings Time within your Entertainment Machine to make sure they are properly set.



Captions and Caption/Text

1 Click on your Setup Menu icon in the menu display.

2 Select Captions in the menu by clicking on it. Click on it again and a display will appear at the bottom of your screen.

3 Choose whether you want the captions Off, On or Caption When Muted.



4 Click on EXIT to return to the Setup Menu.

5 Select Caption/Text from the menu by clicking on it. Click again to reach the Caption/Text display.

6 Choose which type of captioning or text you want by clicking on that item.

7 Click EXIT to return to the Setup menu. Click on the regular screen to return to normal viewing.

Turn closed captioning or text on, off, or have it appear automatically.



Choose Caption 1 to view traditional Closed Captioning.



With the Trakball, you can also go to the PIP/Features menu and click on "CC" to enter the Captions menu. See page 18.



Not all programs have captions.


Mini glossary

CAPTIONS	A form of subtitling that writes out the dialog for your program.
TEXT	Arbitrary text not related to the program.
CAPTION WHEN MUTED	Sets captioning to come on automatically when your volume is soft muted or muted.

Language Menu

Choose what language your on-screen menus appear in.


- 1** Click on your Setup Menu icon in the menu display.
- 2** Select Language by clicking on it. Click again and the Language Menu will appear at the bottom of your screen.
- 3** Choose the language you want by clicking on English, Spanish, or French.
- 4** Click on EXIT to return to the Setup Menu.
- 5** Click on the regular screen to return to normal viewing.



Background

- 1** Click on your Setup Menu icon in the menu display.
- 2** Select Background by clicking on it in the menu.
- 3** Choose whether you want an opaque background Off or On by clicking on your choice.
- 4** Click on EXIT to return to the Setup menu.
- 5** Click on another option to alter, or on the regular screen again to return to normal viewing.

Customize the look of your on-screen menus.



Turning your Background On makes reading the menus easier.

Timer Setup: Sleep Timer

Have your Entertainment Machine go to sleep any time.

- 1

Click on your Features Menu icon in the menu display.
- 2

Select Timer Setup in the menu by clicking on it. Click on it again and the Timer Menu will appear, replacing the features Menu.
- 3

Click on Sleep Timer in the menu to highlight the feature. Click it again to specify an amount of time before your Entertainment Machine turns itself off.
- 4

You can increase or decrease the amount of time in increments up to four hours by clicking on the time display, or using the Left/Right arrows on the bottom of your remote.
- 5


Click on EXIT to return to the Timer Menu.



The sleep timer can also be accessed by the moon and stars icon on the top of the PIP/Features menu. See page 18.



As the Good Night Display counts down the final 60 seconds, the audio and video of the Entertainment Machine “dim” for a soft discreet turn-off.



Timer Setup: On/Off Timer

Have your Entertainment Machine wake up and go to sleep any time.

1 Click on your Features Menu icon in the menu display.

2 Select Timer Setup in the menu by clicking on it. The Timer Menu will appear, replacing the Features menu.

3 Click on On Time first to highlight the feature and a second time to set the time your Entertainment Machine turns itself on. A display will appear at the bottom of your screen. The number appears in the form (HH:MM AM). Select the amount time by entering a number using your NUMBER PAD on your remote. Select AM or PM by pushing the FLSHBK button repeatedly on the remote, or simply click on AM/PM.




4 Click on EXIT to return to the Timer Menu.

5 Click on Off Time to highlight the feature and a second time to set the time your Entertainment Machine will turn itself off. Repeat step number 3 to enter an Off time.

6 Click on EXIT to return to the Timer Menu.

7 Click on On/Off Timer to decide if your Entertainment Machine will observe the times you entered above. Select ON and it will shut off and turn on at the specified times.

8 Click on EXIT to return to the Timer Menu.



To activate the On/Off Timer, you must set an Off Time. The On time is optional.

Channel Labels

Choose preset labels for channels or create your own.

1 Click on your Features icon in the menu display.

2 Select Ch. Labels by clicking on it. Click again and a blue screen will fill with a list of possible channel labels. The current channel will appear in the upper-right corner inset.

3 Choose a channel to label with the Channel Up/Down display on the right side of your screen.

4 Choose a label for the channel by clicking on it.



NOTE: The (---) label indicates that your TV will accept the original, broadcast label if sent by the broadcaster, and (None) will block all labeling.

5 To edit any of the labels, click on the label again or select EDIT at the right side of the screen. Another screen will appear with the alphabet. Click on any of up to four letters, then click EXIT to return to the Channel Label screen.

6 Click EXIT to accept the label and return to the Features menu. Click on the regular screen to return to normal viewing.



If you watch cable with a cable box and have your channel set to 3 or 4, you should set the label to None.



Source ID

1

Click on your Features Menu icon in the menu display.

2

Select Source ID by clicking on it. Click it again to enter the Source ID menu. Your screen will be replaced by a blue one that lists all the sources and their current labels.

3

Select the Source name you want by clicking on it. Click repeatedly on the label to cycle through all the available names.

Note: The (---) label indicates that your source name will be the default name shown in the source column.

4

If you don't see a name that you want, click on EDIT to enter the label edit screen. A customizable alphabet feature will appear. To customize the name, click on the letters of the name you want (up to 10 characters). Click on EXIT to return to the Source ID screen.



5

When you're done, click on EXIT to return to the Features menu.

6

Click on another selection, or on the regular screen to return to normal viewing.

Name the sources for the Entertainment Machine with Source ID.



The titles under Source will correspond to the jack labels on the back of your Entertainment Machine.

The titles under Label will change as you click on the source name. If the dashes are chosen, the source name will be the default name as it appears above (under the Source).



Source IDs can be edited and re-edited every time you rearrange your equipment. Make sure to keep track!



Sources can be disabled by choosing that option under label so they will not appear in the source menu or when pressing the source button.



If you want to return a label to the default name, edit the name using all spaces in place of letters.



Surf ID

Customize the names of your surf channel lists for up to four people.

- 1

Click on your Features Menu icon in the menu display.
- 2

Click on the Surf ID item in the menu. Click again and your screen will be replaced by a blue one, showing all your available surf lists.
- 3

Highlight the Surf channel list you want to edit by clicking on it. Click repeatedly on the label to cycle through the available names.

Note:

Be sure to indicate the specific channel list you wish to edit. For example, Surf 2 should be selected if Surf 1 has already been edited.

- 4

Click on EDIT to enter the label edit screen. An alphabet, including some symbols will appear. Spell out the name you want by clicking on one letter after the other (up to 10 characters). Click on EXIT to return to the Surf ID screen.
- 5



Click on another Surf channel list to continue editing, or click on EXIT to return to the Features Menu. To program Surf 2, 3, and 4, click on those specific options and repeat steps one through four above. See page 23 for additional information.
- 6

Click on another option, or click on the regular screen to return to normal viewing.

- 

If you want to return a label to the default name, edit the name using all spaces in place of letters.
- 

Customized surf channel lists can be disabled by choosing that option under label so they will not appear in the surfing display when pressing the surf button.



The titles under Label will change as you click on the Surf name. If the dashes are chosen, the Surf name will be the default name as it appears above (under the word Surf).



Parental Control

Determine the channels and video your kids can access.

1

Click on your Features icon in the menu display.

2

Select Parental Ctl. in the menu by clicking on it. Click again to enter the parental control menu (Par. Ctl.).

3

Click on Block Ch. and the screen will be replaced by a blue screen listing all of your available channels. Click on the channel numbers that you wish to block. The screen lists the channel as Unblocked. Click on the channel again and it will read Blocked. Click EXIT to return to the parental control menu.

4

Click Block Video and you will be given the option to block all Video inputs except Ant/Cable 1 and 2.

5



Select Set Hours in the menu by clicking on it. Click again to set the amount of time you want the channel blocked for: 1 to 99 hours. Click on arrows to increase or decrease the time. Click EXIT to return to the parental controls menu.

6

Click on Set Password twice to choose a number that will protect the channel. A display will appear on the bottom of your screen, prompting you to enter a four-digit code. Click on any four numbers from the list, or enter a number using the NUMBER KEYPAD on your remote. After you enter it once, you must enter it again to verify it. After you verify the password, the screen automatically displays Lock On/Off

7

Click On or Off to have your Entertainment Machine enable the channel blocking (On), or to ignore it (Off).



If you do not set the hours or password, you will not be able to enable the blocked feature.



Should you forget the password you activated, parental control will automatically deactivate when the preset time expires, which cannot be adjusted.

Auto Demo

Your Entertainment Machine will show you all your menu options.

- 1


Click on your Features Menu icon in the menu display.
- 2

Select Auto Demo in the menu by clicking on it. Click on it again, and a display will appear at the bottom of your screen.
- 3

Decide whether you want the Auto Demo On or Off, and click on that option.
- 4

Click on EXIT to return to the Features Menu.
- 5

Click on the regular screen to have the Auto Demo begin.



Auto Demo displays many of the menus and displays your Zenith Entertainment Machine has, showing you the layout and location of your options.



To let you know it's running, Auto Demo places an animated icon in the upper-right corner of your screen.




Pressing any key on the remote or front panel of your Entertainment Machine will temporarily stop the demo. To cancel the demo, you must turn off the Auto Demo.

Audio Menu

1

Click on your Audio Menu icon from the menu display. Your options are:

- **Bass:** Increase/decrease lower-end sounds.
- **Treble:** Increase/decrease higher-end sounds.
- **Balance:** Allows you to put the sound more to the left or right channel.
- **Audio Mode:** Choose from stereo sound, mono, or Second Audio Programming (SAP).
- **SoundRite:** Scans for changes in sound level during commercials, then adjusts the sound to match your current level.
- **Front Surr:** Turn the front surround sound speakers on or off.
- **Rear Surr:** Increase or decrease the sound level of the rear surround speakers.
- **BBE Audio:** Choose the level the BBE Sound Control is set to.
- **Speakers:** Turn the regular speakers on or off.



Customize the sound on your Entertainment Machine.

2

Click once on the item you want to modify to highlight it.

3

Click again to enter the menu that lets you change the settings. You will be able to either click directly on any part of the adjustment bar, or on arrows to increase and decrease settings one step at a time.

4

Click on EXIT to return to the Audio Menu. Click on the regular screen to return to normal viewing.



Not all programming is broadcast in stereo sound.



Programming that doesn't broadcast SAP may be silent when you set your Entertainment Machine on this setting.

Mini glossary

STEREO SOUND	Stereo (stereophonic) sound refers to audio that has right and left signals.
MONO SOUND	Mono (monaural) sound is one channel of sound. On more than one speaker all the speakers play the same audio.
2ND AUDIO/SAP	Second Audio Programming (SAP) is another, separate, audio channel available with some programming. Choosing SAP often refers to listening to audio in another language, such as Spanish or French.
BBE SOUND CONTROL	Expands the range of tones your sound system delivers, giving you higher highs, and lower lows.

Video Menu

Customize the picture quality on your Entertainment Machine.

1

Click on your Video Menu icon from the menu display. Your options are:

- **Contrast:** Changes the amount of difference between black levels and white levels in your picture.
- **Brightness:** Increases or decreases the amount of white in your picture.
- **Color:** Adjust levels of all colors.
- **Tint:** Adjust the relative amounts of the color red and green in your picture.
- **Sharpness:** Raise or lower the definition of the picture. The lower the level, the softer the image will appear.
- **Color Temp:** Adjust the color qualities of the entire picture at once: warm, medium, and cool.
- **Video Filter:** Reduces noise to enhance picture clarity.
- **Skin Tone:** Automatically adjusts the appearance of skin color, making it more natural.
- **Video Preset:** Choose from a range of options depending on your viewing situation. Custom uses the settings you have manually chosen, while Preset restores the levels to their original settings.

2


Click on the item you want to modify to highlight it.

3

Click again to enter the menu that lets you change the settings. You will be able to either click directly on any part of the adjustment bar, or on arrows to increase and decrease settings one at a time.

4

Click on EXIT to return to the Video Menu. Click on the regular screen to return to normal viewing.



Someone left the picture looking terrible? Just choose Preset under Video Preset to get the regular picture back quickly.



Your modified video selections can be different for each source. Modifying the settings in one source will not change settings in another source.

PIP Overview

Picture-in-picture explained.

YOUR PICTURE-IN-PICTURE FEATURE

The Picture-In-Picture (PIP) function allows you to put a smaller picture, called the “inset,” on the bigger screen, or the “main” picture. Don’t want to miss any of the big game, but hate commercials? Just put the game in the inset, and surf with the main picture.

2-TUNER PIP FEATURE

Normally, you would need some other piece of equipment, like a VCR, to act as a tuner to receive and display a second channel at the same time. Your Entertainment Machine eliminates that need by giving you two tuners in one TV. PIP is always available, no matter what equipment you have.

WORKING WITH PIP

This is where your MBR Trakball remote is put to the most use. All of the functions PIP has are accessible through the menus that pop up on-screen when you use your Trakball. There’s more about that on the following page.

Just like your Entertainment Machine’s main screen, PIP will need a source to take its image from. When you set the main screen source to Antenna/Cable 1 or 2, the PIP source will automatically set to that as well. You can adjust and/or request a different source under the Source menu (see page 22).

PIP SNAPSHOT


This feature enables you to freeze the main image into the PIP frame or view another image in the PIP frame with the touch of a button.

POSSIBLE REASONS FOR ADJUSTING PIP SOURCE

1. You use a cable box to receive premium channels, and have it “looped out” on the back of the TV. Set the PIP source to the cable box source, and the Inset will display the premium channels, which can then be swapped with the main picture.
2. You want to watch a video tape, but keep scanning for another movie or game. Set the PIP source to VIDEO 1, 2, or 3 and you can watch the VCR and TV, swapping between the two.




You cannot have the Main Source from Ant/Cable 1 and the PIP source in Ant/Cable 2 or vice versa. PIP must be the same Ant/Cable source as the main or one of the video sources.



PIP/Features Menu

Getting the most from the PIP and other functions with your remote.

The PIP functions can all be found in the on-screen menu that appears when you roll the pointer to the left side of the screen.



PIP Menu

Control the picture qualities of your PIP inset.

- 1

Click on your PIP Menu icon in the menu display.
- 2

Select Size in the menu by clicking on it once.
- 3


Click on it again and a display will appear at the bottom of your screen. You have two sizes available for the PIP inset picture: Small and Large.
- 4

Click on the size you want your PIP inset to be. The inset will appear and change size to show you the difference, even if the PIP has not been turned on.
- 5

To return to the menu and adjust the other options, Contrast and Tint, click on EXIT. Click on the regular screen to return to normal viewing. The PIP will then disappear if it has not been turned on.
- Note: Contrast and Tint are adjusted the same as they are in the Video Menu, only now they affect the PIP inset image. See Video Menu page 36.



All the rest of the PIP options are available using your Trakball. See page 38 for a full description.



Mini glossary

PIP This is the most common way to refer to the Picture-In-Picture (PIP) option.

Controlling
the Main
and PIP
audio/video
using your
Trakball.

Channel/Time and PIP Display

Some functions of PIP can also be controlled using the Channel/Time display.

- 1

Turn PIP on. Click the Trakball once, and roll the pointer to the right side of the screen.
- 2

The display will be in two parts. The highlighted part will indicate the mode you're in (Main or PIP). Click on the darkened part to change to operating the other mode.
- 3

If the bottom section (PIP) is highlighted, you'll be changing stations in the PIP inset. To change stations on the main picture, highlight the top half before changing channels.
- 4

Instead of going to the Audio Swap option in the PIP/Features Menu, simply click on the small musical note icon on the left of the Channel/Time display. The note that is highlighted tells you which audio you are listening to.



You can be listening to the PIP audio, but still changing the main picture's channel.



♫

Ch 07 - NBC

4:55

Mono

PIP

Ch. 05

Ch. ⬆

Ch. ⬇

All Chan

Flashback

Surf 1





♫

Ch 07 - NBC

4:55

Mono

PIP

Ch. 05

Ch. ⬆

Ch. ⬇

All Chan

Flashback

Surf 1



3357-o

Using your MBR Trakball Buttons

You can use most of the options on your Entertainment Machine by pressing various buttons.

MENUS

Pressing the MENU button repeatedly will cycle you through all the available menus that control your Entertainment Machine's settings.

Once in a menu, you can select an item by pressing the UP/DOWN arrows to highlight one. Then, to modify that option, you can choose it by pressing a RIGHT/LEFT arrow.

Changing labels and I.D.s require modifying options from a blue-screen menu. In these menus all four of the arrow buttons will move the cursor around the screen. Pressing FLSHBK will cycle through options where the screen indicates.

Pressing ENTER will leave your current menu, and bring up the Time/Channel Display. QUIT will leave the current menu, and take everything off your screen.

SURF

The SURF button on your remote will cycle you through your four surf menus.

The current Surf list will appear in the Surf display in lower right of your screen. Surf 1-4 means that your channel changing using the channel up or down will be limited to the channels that have been chosen for your Surf list. When the list display reads No Surfing, then all added channels will be available for you to choose from when channeling up or down.

MODE


Your remote control can operate up to five different pieces of equipment. These are called its "modes." When you are using the remote to operate your Entertainment Machine, it is in TV mode, VCR mode when operating your VCR, and so on. There are modes available to control two "Auxiliary" items. This is for an external stereo system, or simply more VCRs, a DVD, Laserdisc, or any other piece of home theater.

You can change the current mode by pressing either left or right on the MODE button. An indicator will light to show you the current mode.

VCR/DVD FUNCTIONS

The buttons at the very bottom of your remote correspond to functions for your Zenith VCR or DVD. The remote has already been programmed with the code that operates most Zenith VCRs, so you can use those buttons without have to go through the programming process. For any other brand, refer to page 43 to see how to program new codes.

Using the buttons on your remote to control your Entertainment Machine.



Front Panel

Using the ten-button front panel to operate the menus.

1 Press POWER on the control panel to turn on your Entertainment Machine.

2 To access the menus, push the MENU button on the control panel. Cycle through the various menus by pushing the button repeatedly.

3 Press the SELECT button repeatedly to highlight the option you want to modify.

4 Press either Right or Left on the ADJUST button to modify the option you have chosen.

5 Push the ENTER button to return to normal TV viewing.




Refer to the various pages on how to use the on-screen menus using your remote.



The CHANNEL and VOLUME buttons work just as they do on your remote control.



Lost the remote? Call Zenith at 1-800-255-6790 to ask about purchasing a new one. Any other brand besides Zenith will not perform all of the possible functions on your TV.



NOTE: The picture for the IQA36A46W and the control panel will be different than the one shown.


Programming the MBR Trakball Remote

- 1** Select the equipment you want to program, then turn to pages 44-45 to find the programming code appropriate for the type and brand of equipment. Make sure the equipment is turned on.
- 2** Point the MBR Trakball remote at the piece you're programming, and press MUTE and FLSHBK at the same time. Hold until one of the mode indicator LEDs lights.
- 3** Use the MODE Right/Left button to select the appropriate mode for your equipment.
- 4** With the Number Keypad, enter the three digit code you found in step 1. If the code is accepted, the mode indicator LED will blink three times. If it is not accepted, the LED will not blink.

NOTE: The TV and VCR modes will only accept codes for those types of products. The AUX 1, AUX 2, and Cable modes will accept codes for any kind of product.
- 5** Push the POWER button to turn off the equipment. If nothing happens, repeat the process from step 1, and try the next code number.



To get out of Programming before you enter a code, just press the QUIT button on your remote.



Operate all of your home theater and stereo hardware with the MBR Trakball.

Programming Codes

Find the codes
you need to
program your
remote.

TVs

Admiral	116 121 130 133	Goldstar	103 104 119 147 184	Montgomery Ward	103 104 105 113 114 119 121 130 133	Sharp	103 105 122 133 137 156 169
Akai	104	Hitachi	102 103 121 129 163	NEC	104 119	Signature 2000 . .	103 104 105 113 114 119 121 130 133
Amark	103 146	Inteq	101	Orion	176	Sony	115 143 151 170
AOC	104	JC Penney	104 110 114 117 119	Panasonic	106 107 160 166	Soundesign	139
Bell + Howell . . .	121	JVC	125 132 164	Philco	103 104 112 113 139	Sylvania	112 113 117 119 127 128 139
Broksonic	131 136	KMC	103	Philips	112 113	Tatung	106
Candle	139	KTV	103 104 138	Pioneer	135	Teknika	103 112 121 124 139
Centurion	119	Kurazai	121	Portland	103	Telerent	103 121
Citizen	121 139	LG	184	ProScan	116 157 162 167	Toshiba	110 111 134 171
Contec	141	Lodgenet	121	Quasar	106 107	XR-1000	121
Coronado	103	Logik	121	RCA	104 116 126 157 161 162 167 168	Yorx	119
Crown	103	LXI	119 133 137	Realistic	105 123 124	Zenith	101 142 149 177
Curtis Mathes . . .	116 119 121	Magnavox	103 112 113 117 119 127 128 130 139 165	Sampo	119	Zenith StarSight . .	175
Daewoo	149 159	Majestic	121	Samsung	103 119 134 141		
Daytron	119	Marantz	104 120 155	Sanyo	108 109 118		
Elektra	121	Megatron	146	Scott	119 124		
Emerson	103 104 123 124 131 136 145 176	Memorex	121	Sears	103 108 109 110 111 118 134		
Fisher	109 118	MGA/Mitsubishi . .	104 119 120 130 133 140 155 169 178				
GE	106 107 114 116 117 161						

TV/VCRs

Adventura	154	Goldstar	153	RCA	179	Symphonic	154
Broksonic	182	Hitachi	154	Samsung	180	XR-1000	154
Emerson	158	LXI	154	Sansui	182	Zenith	153 154 172 182 183
Daewoo	148	Magnavox	173 181	Sharp	179		
Funai	154	Panasonic	174	Sylvania	154		

VCRs

Admiral	208 261	GE	214 216 220	NEC	202 218	Sharp	208 261 272
Adventura	231	Go Video	256 262 263 275	Optimus	208 209 259	Shintom	239
Aiwa	231	Goldstar	209 273	Orion	233 250	Signature 2000 . .	208 214 216 219 231 249 261
Akai	223 238 241	Hitachi	215 231 257	Panasonic	214 251 259	Sony	232 274
Audio Dynamics . .	202 218 206 247	Instant Replay . .	214 227	Pentax	215	Sony Beta/VHS . .	237
Broksonic	221 226 233 250 255	Inteq	273	Philco	207 214	SonyVideo8	217
Canon	214	JC Penney	214 215 218 227	Philips	207 214 227	Sylvania	207 214 227
Citizen	209	JVC	202 224 225 258 268	Pioneer	210 215	Symphonic	231
Craig	212	Kenwood	202	Portland	246	Tashiko	209
Criterion	239	Logik	239	ProScan	216 260	Tatung	202
Curtis Mathes . . .	214	LXI	209 231	Quasar	214 259	Teac	202 231
Curtis Mathes . . .	259	Magnavox	207 214 231	RCA	215 216 220 227 240 242 249 260 267	Teknika	209 234
Daewoo	244 246 248 254	Marentz	207 218	Realistic	206 208 212 214 231	Toshiba	205 215 271
Daytron	236 246	Marta	209	Samsung	220 230 238	Vector Research . .	204 218
DBX	202 218	Memorex	206 212 214 231	Sansui	239	XR-1000	239
Emerson	203 209 221 223 226 233 235 243 250	Mitsubishi	204 222 252 264	Sanyo	206 212 247	Yamaha	202 218
Fisher	211 212 213 247	Montgomery Ward	208 214 216 219 231 249	Scott	204 205 233 243	Zenith	201 224 225 229 273
Funai	231	Multi Tech	239	Sears	206 209 211 212 215	Zenith Beta	237

Programming Codes

Find the codes you need to program your remote.

CABLE/SATELLITE/SET-TOPS

Allegro 358 362	JVC Satellite. 389	Primestar Satellite 388	Unika 348
Allegro A-B Switch 361	Kale Vision. 335	RCA DSS 373 394	Unika 362
Americast 383	Macom 321	Radio Shack 362	United Satellite . . 344
DISH Network Satellite 389	Macom Satellite . . 314	Regal 366	Universal. 358 362
GE 367	Magnavox 334	Regency 329	Vid Tech 340
Gemini 305 331 338	Magnavox DSS . . . 390	Samsung 335	Video Way 349
General Instrument 304 305 306 307 308 309 310 318	NSC 335 339 368 369 370	Scientific Atlanta 316 323 336 364	Viewstar 354 355 369 372
Hamlin 302 303 345 365 366	Oak 311 332 342	Sony DSS. 387	Zenith. 301
Hitachi DSS 392 393	Panasonic 313 320	Sprucer 313	Zenith HT-2000. . . 353
Hughes DSS 392	Panasonic DSS . . . 386	Standard Comp . . . 335	Zenith PM 374
Jerrold 304 307 308 309 310 318 360 363 382	Paragon (Zenith) . . 333	Stargate 379	Zenith Drake Satellite 312 330
	Philips 347 350 352 354 355	Texscan 339 356 371	Zenith HD Set-Top 385
	Pioneer 315 343	Tocom. 317 318 346	Zenith N C Set-Top. 384 395
		Toshiba DSS 391	Zenith Satellite. . . 328 351 378

LASER DISC PLAYERS

Denon. 402 403	Panasonic 405	Sanyo 401	Zenith. 401
Mitsubishi 403	Pioneer 402 403	Sony. 404	

AUDIO TAPE DECKS

Denon. 455	Kenwood 450	Pioneer 451 478	Technics DCC 454
Harman/Kardon. . . 456	Onkyo. 458	Sony. 452	Yamaha 453
JVC 457	Philips DCC 454	Technics 497	

AUDIO CD PLAYERS

Akai 409 424	Magnavox 421 422 433 434	Quasar 432	Sylvania 433
Carver. 510	Mitsubishi 423 424	Radio Shack 431 436 439 440 441	Teac 446
Crown 410	NAD 425 426 447	RCA 437	Technics 432 459
Denon. 411	Nakamichi 427 428	Sanyo 438 439	Toshiba 447
Fisher 412 438	NEC 429	Scott 440	Yamaha 448
Goldstar 460	Onkyo 430	Sharp 441 442	Zenith. 460 461 498 501 502
Harman/Kardon. . . 413	Panasonic 431 432	Sony. 443 444 445	
JVC 415	Philips 421 433 434	Soundesign 461 498 501 502	
Kenwood 412 416 417 441	Pioneer 431 435		

DVD PLAYERS

Denon. 523 524	Panasonic 523 524	Proscan 526	Toshiba 521
Marantz. 521	Philips/Magnavox 521	RCA 526	Zenith. 521
Mitsubishi 525	Pioneer 527	Sony. 522	

AUDIO TUNER AND AMPLIFIERS

Carver. 510	Marantz. 472 503	RCA 508	Soundesign 461 498 501 502
Denon. 462 463	Onkyo 473	Realistic 480	Teac 494 495
Fisher 464 505	Panasonic 507	Sanyo 481	Technics 497 507 509
Goldstar 460	Philips 475 476	Scott 482	Yamaha 496
Harman/Kardon. . . 465	Philips/Magnavox 505	Sharp 483	Zenith. 460 461 498 501 502 504 505
JVC 466	Pioneer 477 478 479	Sherwood 487 488	
Kenwood 468 469 506	Radio Shack 487 488	Sony. 489 490 491 492	

Auto Find

Use the Remote control to search for all possible programming codes.


- 1** Turn on the device you want to operate.
- 2** Press and hold the MUTE and FLSHBK buttons until the indicator light turns on.
- 3** Press MODE Left/Right until the indicator light is underneath the device you're trying to program (TV, CABLE, VCR, AUX).
- 4** With the NUMBER keypad, enter the code 0-0-0 (zero-zero-zero), then press the Enter key right away.
- 5** Aim the remote at the correct device and push the Power button. Allow a second to pass, then push the Power button again. Repeat until the device turns off.
- 6** Push Enter to save the code. The indicator light on the remote will blink three times and then turn off.
- 7** Press Power to turn the device back on.



You can get out of Auto Find quickly by pressing the Quit button.



If the indicator light does not turn off while you push the Power key, all the codes have been tried and your device can't be programmed.



Amplifier/Cable Volume Override

Amplifier Volume Override:

- 1** Find the code that operates your amplifier. Test it to make sure it's the correct one by following the procedure in the "Programming Your Remote" section.
- 2** Press and hold MUTE and FLSHBK on your remote until the indicator light stays lit.
- 3** Press MODE Left/Right until the indicator light is under the mode that you want Amplifier Volume to appear, for example, TV.
- 4** Enter the code for your amplifier (found from step one).
- 5** Enter the special code: 4-9-9, then quickly press the ENTER button. (The indicator should blink and then turn off.)

Cable Volume Override:


- 6** To program your remote to operate your cable box's volume and muting controls, repeat steps 1-5 using special code 3-9-9.



Your volume and mute keys now control your amplifier, while all the other keys still operate the Entertainment Machine. To change everything back to default, reprogram all buttons with their original codes. See the "Programming Your Remote" section, page 43.



If you can't find the code for your amplifier, use the Auto Find feature.



Control the volume on your sound amplifier while in other modes.

Mini glossary

AMPLIFIER An external machine that amplifies sound from a television, CD player, VCR, DVD or other A/V device.

Caring
for your
Entertainment
Machine.

Maintenance

Careful and regular cleaning can extend the amount of time you will have with your new Entertainment Machine. Be sure to turn the power off and pull out the plug before you begin any cleaning.

SCREEN CLEANING

1. Spray a small amount of glass cleaner on a soft cloth and wipe the screen until it's clean.
2. Here's a great way to keep the dust off your screen for a while. Wet a soft cloth in a mixture of lukewarm water and a little fabric softener or dish washing detergent. Wring the cloth until it's almost dry, and then use it to wipe the screen.
3. Make sure the excess water is off the screen, and then let it air-dry before you turn on your Entertainment Machine.

CABINET CLEANING

1. Use a soft cloth with a mild soap solution to wipe the cabinet (avoid using any cleaner that says "industrial strength" on the label).
2. Rinse the cloth and wipe the cabinet again.
3. Let the cabinet air-dry before turning the Entertainment Machine on.

EXTENDED ABSENCE

If you leave your Entertainment Machine dormant for a long time (such as a vacation), it's a good idea to unplug the power to protect against possible damage from lightning or power surges. If you use an off-air antenna, you may also want to disconnect it from the back of your Entertainment Machine before leaving.

PICTURE INTERFERENCE

Even though you may be getting cable, the signal may be weak, which means the quality of your picture may suffer due to other factors. If there are problems with the image on your Entertainment Machine, consult the Troubleshooting guide on the following pages.

VIDEO GAMES AND OTHER FIXED-PATTERN DISPLAYS

If you use your Entertainment Machine to play video games or for other uses that have single, fixed images, such as a photo-CD player, you should avoid setting the Brightness level too high. If static images, like network identification patterns, are left sitting for too long, they can leave a permanent impression on the picture tube. You can reduce the chance of this happening by limiting the amount of time you use the fixed-image display, and by reducing the contrast and brightness levels or using the Game preset.

CLEANING THE TRAKBALL

Sometimes the Trakball gets greasy or dirty, which can affect its performance. To clean it, moisten a cloth with a solution of dish washing detergent and water. Gently wipe the exposed area of the Trakball, rolling it with your thumb. Allow the remote to dry before using it again.

NOTE: Do NOT use alcohol or other "cleaning fluids" anywhere on the remote control.



If you unplug your Entertainment Machine, you may have to reset the clock using the Clock Set menu described earlier.

Troubleshooting

Some quick and easy tips to fixing problems yourself.

SYMPTOMS	SOLUTIONS
Snowy picture and unclear sound.	• Check your antenna connection or location • Check your cable input. • Check to see if the TV/.VCR button on your VCR has the TV selected.
Multiple images or 'ghost shadows.'	• Check your antenna direction and/or location. • Check your cable input • Make sure the cable from your antenna to your Entertainment Machine is properly connected.
Interference: Sharp lines across the screen and lousy sound.	<i>The following may cause image problems or distortion: Electrical appliances, powerful lights, cars, trucks; computers or portable phones; medical equipment</i> • If possible increase the distance between your Entertainment Machine and the offending appliance. Or shut one of them off.
Normal picture but no sound.	• Check volume levels. • Make sure the TV is not Muted. • Try another channel. The problem may be the broadcast, not your Entertainment Machine. • Are the Audio A/V cables properly installed? • Are the wires for external speakers (if you have external speakers) properly installed? • Make sure your speakers turned on under the Audio menu. • If your audio mode is set to SAP, that channel may not have a SAP program.
No picture and unclear sound.	• Are you in TV or cable tuning mode, and should be in the other? • Make sure output channels on all A/V equipment are on the same channel (3 or 4). • Check that all connections are tight.
No picture and no sound.	• Is the AC power plugged in? • Check that your AC power outlet works. (Test it by plugging in something else or try another plug.) • Make sure your brightness and audio controls are set properly. • Try another channel. The problem may be with the broadcast.
No color, but the sound is O.K.	• Check the color control in the Video menu. • Try another channel. The problem may be with the broadcast.
Picture has a big black box on it, but the sound is O.K.	• The CC (closed caption) option may be in Text mode. Select Caption 1, or OFF in the Captions/Text menu.(See page 25).
Picture has two horizontal black bars, one on top and one on bottom.	• Your program is in letterbox. This means that the shape of your TV is a square, but the program is a rectangle. Think of the bars as empty space the program doesn't fill; not picture that's blocked out. Because this format is a direct representation of film as you see it in the movies, you are actually seeing MORE of the program when you see those bars. Trust us.

Some quick
and easy
tips to fixing
problems
yourself.

Troubleshooting, cont'd

Remote control doesn't work.	• Make sure the batteries are fresh and installed properly.
Indicator light on remote comes on but remote doesn't transmit.	• Make sure the battery on the single side (located on bottom right when remote transmitter is pointed toward the Entertainment Machine) is polarized properly (see page 13).
Menu options can't be changed or selected.	• Try unplugging your Entertainment Machine for a few minutes, then plug it back in.
No picture or sound when any non-cable source is selected.	• Check to see if the source equipment has been turned on. • Make sure that the connections are secure on the back of your Entertainment Machine and on the source equipment.
Weak or no Stereo Sound when using a stereo VCR.	• Check to see if all the connections are secure. • Look in the Audio mode menu to see if all the settings are correct. • You are using channel 3 or 4 to view your VCR. No stereo sound is present under that decision.
Desired PIP source is not selectable.	• Your Entertainment Machine automatically sets the PIP source to Antenna/Cable 1 or 2 if that is the source for the main picture.
The PIP inset is black or lacks contrast .	• You might want to adjust the PIP picture settings under the PIP menu. • Check that all the wires are connected properly. • Check to see if your input source for PIP is set correctly.
The PIP inset is "snow" when the source is Ant/Cable 1 or 2.	• Look to see if the TV/VCR button on your VCR has the TV selected.
Time is incorrect.	• Automatic: Check to see if PBS Channel is correct and then check Time Zone/Daylight Savings time settings under Clock menu. • Manual: Make sure the time was set initially. Probably power was lost.



*If all else fails, call 1-800-365-1690, Mon-Fri. between 7:00 am and 8:00 pm
Sat. 8:00 a.m. and 5:00 p.m. Central Standard Time.*

Special Features

Here are a few features that make your Entertainment Machine more fun to use.

ADVANCED SURF

In addition to your normal channel listing, you can customize up to four different channel lists to fit different members of your family: movie channels for the kids, the sports channel for Dad, etc. See page 23 to set up surf channel lists and page 32 to customize the names of your channel lists.

PIP SNAPSHOT

With the press of a button you can freeze the image from your main screen into a large PIP inset. Pressing the button a second time enables normal PIP viewing. Pressing the button a third time removes PIP from the main screen. See pages 37-39.

AUTOMATIC TIME SET

You can have your Entertainment Machine read a signal sent over PBS broadcasts, and set the time and date automatically. See page 24.

CHANNEL LABELS

Instead of leaving it up to channel numbers to let you know what you're watching, you can choose labels for the various channels (HBO, CNN, ABC, etc.). You can also let the Entertainment Machine use the labels that some stations broadcast themselves. See Channel Labels, page 30.

SOURCE ID CUSTOMIZING

If you have a number of other pieces hooked up to your Entertainment Machine, instead of trying to remember the name of the jack you hooked them up to, just refer to page 31 to customize the name of the equipment as it shows up under the Source Menu or on your Channel/Time display.

PARENTAL CONTROL

Using a password-protection system, parents can block a channel that they don't want their kids to be watching. See page 33.

2-TUNER PIP

Televisions require to a tuner to turn signals into watchable programs. Conventional TV's only have one tuner, and require another machine, such as a VCR, to receive another set of signals to use Picture-In-Picture. Your Entertainment Machine has a second tuner built right in, so there is no need to rely on other equipment for your PIP display. See PIP overview on page 37.

AUTO DEMO

To familiarize yourself with the layout of all your menu options and choices, Auto Demo can be turned on. It will cycle through all the menus, displaying them on your screen for a few seconds. See page 34.

Glossary

A complete list of definitions for words found in this guide.

2-TUNER PIP	This feature allows you to view a second channel while maintaining a picture on the main screen.
75 OHM RF CABLE	The round cable that comes from an off-air antenna or cable service provider. Each end looks like a hex shaped nut with a wire sticking through the middle, and it screws onto the threaded jack on the back of your TV.
A/V CABLES	Audio/Video cables. Three cables bunched together—Right audio (red), Left audio (white), and Video (yellow). A/V cables are used for stereo playback of videocassettes and for higher quality picture and sound from other A/V devices.
A/V DEVICE	Any device that produces video or sound (VCR, DVD, cable box, or television).
ADD	This function lets you add new channels to the list that you'll scroll through when using your remote.
AMPLIFIER	An external machine that amplifies sound from a television, CD player, VCR, DVD or other A/V device.
ANTENNA	The physical receiver of television signals sent over the air. A large metal piece of equipment does not always have to be visible for your home to be using an antenna.
BBE SOUND CONTROL	Expands the range of tones your surround sound system delivers, giving you higher highs, and lower lows.
CAPTIONS	A form of subtitling that writes out the dialog for your program.
CAPTIONS WHEN MUTED	Sets captioning to come on automatically when your volume is soft muted or muted.
CLICK	The act of pressing the Trakball on your remote to perform highlighting, and activating a particular function/feature.
COMPONENT VIDEO	Some video equipment (DVD, for example) uses three separate lines (Y, R-Y, B-Y) to more precisely reproduce images. Your manual will explain how this relates to your equipment.
CONVERGENCE	This option lets you correct for color separation in your picture.
DATA PORT	A jack for hooking up optional equipment that gives you access to the Internet through your TV.
DAYLIGHT SAVINGS	"Observed" means that your Entertainment Machine will adjust your time setting at the appropriate times of the year. "Not Observed" will not. Set this depending on whether your viewing area uses Daylight Savings or not.
DELETE	This function lets you remove channels that you don't watch from the list you'll scroll through.

Glossary, cont'd

A complete list of definitions for words found in this guide.

ICON	A small graphic item on your screen that represents a function or menu item.
INPUT	Refers to the jack that receives a signal into the TV, VCR or other A/V device.
JACK	A connection on the back of a TV, VCR, or any other A/V device. This includes the RF jacks and the Audio/Video jacks that are color-coded.
MODE	The mode determines the type of device (TV, VCR, Cable, Aux) that the remote is controlling.
MONO SOUND	Mono (monaural) sound is one channel of sound. On more than one speaker all the speakers play the same audio.
OUTPUT	Refers to the jack that sends a signal out of a VCR, DVD, or other A/V device.
PIP	This is the most common way to refer to the Picture-In-Picture (PIP) option.
PIP SNAPSHOT	Press to capture and freeze main picture within large PIP frame. Press a second time and receive normal PIP from another channel. Press again to remove PIP from the screen.
POINTER	The image of the hand that appears on-screen and points to the option you want to work with.
SECOND AUDIO PROGRAMMING/SAP	Second Audio Programming (SAP) is another, separate, audio channel available with some programming. Choosing SAP often refers to listening to audio in another language, such as Spanish or French.
SIGNAL	Picture and sound traveling through cable, or on the air, to your television screen.
SOURCE	The term for the equipment that provides audio and video information to your Entertainment Machine. Antenna, VCR, DVD players, or Cable Boxes are examples of sources.
STEREO SOUND	Stereo (stereophonic) sound refers to audio that's divided into right and left sides.
SURF	This function creates a customized list of your favorite channels. You can access this group of channels by pushing the surf button on the remote.
TEXT	Arbitrary text not related to the program.
TUNER	Any device that picks up broadcast signals and turns them into picture and sound.

Index

Find what you
want quickly.

FEATURE	PAGE
2-Tuner PIP	37, 51
Add/Del/Surf-Advanced Surf	23
Amplifier/Cable Volume Override	47
Antenna Hookup	6
Audio Hookups	10-12
Audio Menu	35
Auto Demo	34
Auto Find	46
Background	27
Basic Television Operation	19
Batteries	13
Button Functions	16, 41
Cable	6-8
Cable Volume Override	47
Caption/Text Menu	25
Channel Labels	30
Channel Search	14
Channel/Time Display	40
Clock Set	24
Component Video	9
Convergence	15
DVD Player	9
External Stereo	12
Front A/V Panel	5
Front Panel Diagram	42
Glossary	52-53
Home Theater Set-up	10
Hookup Directory	3
Jack Pack	4
Language Menu	26
Loop Out	7
Maintenance	48

Index, cont'd

Find what you
want quickly.

FEATURE	PAGE
On/Off Timer	29
On Screen Menus	20-21
Parental Control	33
Picture-in-Picture (PIP)	37-38
PIP Menu	39
PIP Snapshot	37, 51
Programming the Remote	43-45
Projo Setup	15
Quick Start	13
Remote Control Diagram	16
Safety Information	2
Serial Number	2
Sleep Timer	28
Source ID	31
Source Menu	22
Special Features	51
Subwoofer	10-11
Surf ID	32
Surround Sound Speakers	10-11
Trakball Remote	16-18
Troubleshooting	49-50
VCR	8
Video Menu	36
Warranty	56



To reach Zenith, call 1-800-365-1690, between 7:00 am and 8:00 pm, Sat. 8:00 a.m. and 8:00 p.m. Central Standard Time.

inteq audio/video accessories

STAND ALONE SUB-WOOFER

The IQ25SW features dual 6-1/2" sub-woofers offering true 25 watts per driven channel and Fixed Bass Boost. This unit is lightweight for easy placement and fits nicely with any decor. The Automatic Standby Circuit cuts out the power after about 5 minutes of no signal so the speakers won't burn out.

IQ25SW ONLY \$349.95 PLUS \$19.95 SHIPPING & HANDLING



STEREO SURROUND SOUND SPEAKERS

For use with any Surround Sound compatible TV. These speakers create a sound so real, it's as if you were part of the action. The convenient, space-saving shelf design make these speakers an ideal addition to any Home Theater System. The contemporary black finish complements any room.

CV5000 ONLY \$224.95 PLUS \$17.95 SHIPPING & HANDLING



SUB-WOOFER CABINET

Powered by dual 6-1/2" sub-woofers, the IQ50SD cabinet provides 25 watts per driven channel and Fixed Bass Boost. The sleek black cabinet features glass doors and an Automatic Standby Circuit that shuts itself down to extend its lifespan. It will accommodate a 35" TV with space to store all your video extras. Approx. dimensions: 36" w x 24.5" d x 20" h.


IQ50SD ONLY \$349.95 PLUS \$19.95 SHIPPING & HANDLING



SURROUND SOUND SPEAKERS

Extra power and the added dimension of surround sound are combined in these two-way mini tower speakers featuring dual 4-1/4" woofers. They're rated up to 100 watts of music power via the sub-woofer crossover for unparalleled audio output. The rear channel speakers are two-way 4-1/4" full range speakers with 15 watts of power. Easy to follow instructions for strategic positioning are included.

IQ8000 ONLY \$349.95 PLUS \$19.95 SHIPPING & HANDLING



REPLACEMENT REMOTE

Broken or lost remote? Perhaps you would just like the convenience of having a second remote on hand. Order your replacement remote control direct from Zenith! To ensure that you receive the correct remote, have your television's model number ready when you call.

ONLY \$39.95 PLUS \$4.95 SHIPPING & HANDLING

Order Today!
Call Toll-Free
1.800.255.6790
Use your Visa
or MasterCard to
order.

zenith|inteq

Your Zenith Limited Warranty

Direct-View Color TV Welcome to the Zenith family! We believe that you will be pleased with your new Zenith Entertainment Machine. Please read this warranty carefully, it is a "LIMITED WARRANTY" as defined under Federal Law. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state within the U.S.A.

ZENITH RESPONSIBILITY

Service Labor	During a period of 90 days from effective warranty date, Zenith will provide service labor by a Zenith authorized service center when needed as determined by Zenith as a result of manufacturing defects.
Parts	New or remanufactured replacements for factory-defective parts will be supplied by a Zenith authorized service center for one year from effective warranty date (color picture tube — two years). Such replacement parts are warranted for the remaining portion of the original warranty period.
Home Service	Warranty service for 21" diagonal (U.S.A.) or larger screen size models is provided in the home in most cases. (Some repairs may require the unit to be taken by the servicer to the repair facility and returned, at no additional charge.)
Not Covered	This warranty covers manufacturing defects and does not cover installation, adjustment of customer controls in the home, installation or repair of home antenna systems, cable converters or cable company-supplied equipment; it also does not cover damage due to misuse, abuse, negligence, acts of God or other causes beyond the control of Zenith. Any alteration of the product after manufacture voids this warranty in its entirety.

OWNER'S RESPONSIBILITY

Effective Warranty Date	Warranty begins on the date of original consumer installation. For your convenience, keep the dealer's dated bill of sale or delivery ticket as evidence of the purchase date.
Operating Guide	Read your Operating Guide carefully so that you will understand the operation of your set and how to adjust the customer controls.
Carry-In Service	Models under 21" diagonal (U.S.A.) screen size must be taken to a Zenith authorized service center for warranty service and must be picked up by the owner.
Antenna	Reception problems caused by inadequate home antenna or faulty antenna connections are the owner's responsibility.
Important	Product Registration—Please fill out and mail your Product Registration Card. It is imperative that Zenith know how to reach you promptly if we should discover a safety problem that could affect you.
Warranty Service	For warranty service information, contact any Zenith authorized service center. Parts and service labor that are Zenith's responsibility (see above) will be provided without charge. Other service is at the owner's expense. If you have any problem in obtaining satisfactory warranty service, call or write the Zenith Response Center. You must provide the model number, serial number and date of purchase or date of original installation. Before you ask for warranty service, read "Maintenance And Troubleshooting" in your operating guide. You might avoid a service call.

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND ZENITH SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, OR INCIDENTAL DAMAGES OF ANY KIND, INCLUDING LOST REVENUES OR PROFITS IN CONNECTION WITH THE PRODUCT.

ZENITH CONSUMER SERVICES

Factory Owned Service Center
Home & Carry-in Service
Television/VCR
Parts and Accessories
PTV/Computer
Service Contracts Hours:
M-F 8-6, Sat 9-2
801 E. Roosevelt Rd
Lombard, IL 630-705-2830

ZENITH ELECTRONICS CORPORATION

Zenith Response Center
1000 Milwaukee Avenue
Glenview, IL 60025-2493
Telephone (847)391-8752
Mon-Fri, 7:00 a.m.-8:00 p.m.
Sat. 8:00 a.m. - 5:00 p.m. CST

IN CANADA, WRITE OR CALL US AT:

LG Electronics
235 Superior Blvd.
Mississauga, Ontario, Canada L5T-2L6
tel: (905)795-6240,
fax:(905) 670-2379

IN MEXICO, WRITE OR CALL US

LG Electronics
Av. San Andres Atoto, No 8
Col. San Andres Atoto, Naucalpan
Estado de Mexico,
C.P. 53500
tel; 01 (800) 50 481
y en el D.F. 359 43 55
fax 01 (800) 50 733
y en el D.F. 357 17 56

Additional Zenith Picture Tube Protection Plan Available

Zenith offers you the opportunity to obtain additional long-term protection against failure of the picture tube in your new television. Our Picture Tube Protection Plan enables you to avoid any unexpected picture tube repair expenses and keep your television in top condition. It guarantees you a genuine Zenith replacement picture tube and service from a Zenith authorized service center.



Be sure to send in the Product Registration Card. We will send you an application for the Protection Plan near the expiration of the two-year manufacturer's warranty on the picture tube. For additional information call (847) 391-8757.